

Logitech®

Wireless Gamepad F710

Console-style control with a cable-free 2.4 GHz connection

- 2.4 GHz wireless connectivity
- Broad game support
- Profiler software
- Dual vibration motors
- Familiar layout

No cords to get in your way. The Logitech® Wireless Gamepad F710 uses a powerful, reliable, cable-free 2.4 GHz connection while dual-motor vibration feedback lets you feel every hit, crash and explosion. Multiple mode settings bring a familiar console-style controller experience to your PC with support for the broadest number of games. Profiler software lets you customise your gamepad with keyboard and mouse inputs*. A classic controller design lets you focus on the game. The unique floating design of the D-pad makes it responsive to quick changes in direction. And rubber grips make game play extra comfortable.

* Requires software installation



SCIENCE WINS.



Wireless Gamepad F710

Package specification

	Primary pack	Master snipper carton
Part # EWR	940-000142	n/a
Bar code	5099206041899 (EAN-13)	50992060418916 (SCC-14)
Part # EER	940-000145	n/a
Bar code	5099206041905 (EAN-13)	50992060419012 (SCC-14)
Weight	406.00 g	1860.00 g
Length	16.80 cm	26.70 cm
Width	7.90 cm	18.70 cm
Height/depth	20.00 cm	18.30 cm
Volume	2.654 dm3	0.0091 m3
1 primary pack	1	n/a
1 intermediate pack	0	n/a
1 master shipper carton	4	1
1 pallet EURO	792	198
1 container 20 ft	12912	3228
1 container 40 ft	26688	6672
1 container 40 ft HQ	31136	7784









Package contents

- Gamepad
- Plug-and-forget nano-receiver2 AA batteries
- Range-extending receiver cable
- User documentation
- 3-year manufacturer's guarantee and full product support

System requirements

- Windows® 8, Windows® 7, Windows Vista[®]
- USB port
- Internet connection for optional software download

Technical Specs

- XInput mode:
 A, B, X, Y buttons LB
- RB buttons
- Left and right analogue triggers
- Start and Back buttons
- Two clickable analogue minijoysticks
- 8-way D-pad
- · Home button
- Sports mode
- Vibration on/off button

DirectInput mode:

- 10 programmable buttons*
- Programmable left and right triggers*
- Two programmable analogue mini-joysticks*
- 8-way programmable D-pad*
- · Sports mode
- Vibration on/off button